

Single Channel Receiver

AL-70-01-0002



SlimDim Wireless Dimmers are a revolution in lighting control. Using long range RF technology, these dimmers avoid the need for connecting directly to a power supply, cutting down on cost and installation time. SlimDims are simple and quick to install with the use of a Single Channel Receiver.

TECHNICAL INFORMATION

- Dimensions: 3.75 x 1.46 x 0.8 in.
- Input Voltage: 12-36V DC
- Output Voltage: 96W (12V) / 192W (24V) per channel
- Max. Current: 8A per channel
- Constant Voltage

OPERATION

How to Pair the SlimDim Single Color Dimmer (AL-70-01-0001 - sold separately) with the Single Channel Receiver

1. Connect the receiver according to the diagram.
2. Turn on the wireless dimmer. The power indicator will light up.
3. Press the "Learning Key" button on the receiver.
4. Touch a button on the controller.
5. The indicator light on the receiver will blink to confirm pairing.

How to Unpair the Receiver and Controller

1. Hold down the "Learning Key" button on the receiver for 5 seconds. When the LED lights flash, the controller has been unpaired.

