



# Casambi® Compatible Wireless 4-Button Dimmer Wall Switch


## INSTRUCTIONS




1) On the Network's main page, select "More"




2) Select "Nearby devices"




3) Look for the sensor you want to pair and select it



4) Select "Add to (network)"




5) Select "Back"




6) Select "Switches"


## INSTRUCTIONS (CONTINUED)




7) Select the switch to configure




8) Rename it to a name of your choice and select a push button to configure




9) Select "Not in use" to change what the button does



10) Select "Controls a luminaire"




11) Select "Luminaire" to select which luminaire(s) to control




12) Select the luminaire(s) to control and select "Done"

## INSTRUCTIONS (CONTINUED)



13) Select "Done" to save the configurations



14) The first push button will now display the luminaire and the action in the button. Select "Back" to finish